



## CANBUS CONNECTIONS (SEEN FROM CABLE OUPUT OF CONNECTORS) rev 1.19








## CANBUS CONNECTIONS (SEEN FROM CABLE OUPUT OF CONNECTORS) rev 1.19








The information in this guide and in its attaches are purely for information purposes, therefore, are subject to change without notice. At the time of publication the information is correct and reliable. However Paser can not be held responsible for any consequences resulting from errors, omissions or incongruence in this manual (for ex. according to missed audio configuration back-up of the vehicles). Paser reserves the right to improve / change the product or manual without obligation to notify users.







## CANBUS CONNECTIONS (SEEN FROM CABLE OUPUT OF CONNECTORS) rev 1.19









## CANBUS CONNECTIONS (SEEN FROM CABLE OUPUT OF CONNECTORS) rev 1.19




# **CANBUS CONNECTIONS** (SEEN FROM CABLE OUPUT OF CONNECTORS) rev 1.19



# **CANBUS CONNECTIONS** (SEEN FROM CABLE OUPUT OF CONNECTORS) rev 1.19



## CANBUS CONNECTIONS (SEEN FROM CABLE OUPUT OF CONNECTORS) rev 1.19



## CANBUS CONNECTIONS (SEEN FROM CABLE OUPUT OF CONNECTORS) rev 1.19

