

# INSTALLATION MANUAL

## MULTICAN EVOLUTION UNIVERSAL CANBUS Adapter for steering wheel commands & PARROT EVOLUTION Handsfree Kit rev 1.14


### DESCRIPTION

**MULTICAN** is a **UNIVERSAL** adapter for steering wheel commands with **CANBUS** protocol vehicles. The module allows you to control the PARROT EVOLUTION Handsfree Kit with the steering wheel commands.

The selection of the protocol comes through **SELF-RECOGNITION**, which means that on the termination of the connections for the insertion of the module to the connector, the unit will carry out, in about a second, the synchronization and the selection of the correct CANBUS protocol of the car on which the module is installed.

### CONNECTIONS

- Connect the power cable of Multican to the 14-way connector of the Multican (1).
- Join the connector of the kit's control keypad to the connector of the interface's power cable (2)
- Connect the Multican ISO power cable to the ISO power cable of the Parrot control unit (3).
- Connect the YELLOW MUTE wire of Multican to the Parrot's YELLOW MUTE wire and to the car stereo MUTE input if available (4).
- Refer to the chapter entitled CANBUS CONNECTIONS to connect the CAN H and CAN L wires (5).



### ATTENTION:

**IGNITION IS SUPPLIED BY MULTICAN.  
DO NOT CONENCT ORANGE WIRE OF THE H/F TO AN IGNITION.  
CONNECT THE YELLOW WIRE OF THE UNIT TOGETHER WITH  
THE YELLOW OF THE H/F!**

### WARRANTY CONDITIONS


THIS PRODUCT IS GUARANTEED FOR 2 YEARS FOR ANY MANUFACTURING DEFECT.  
THE PURCHASING FISCAL DOCUMENT SERVES AS THE GUARANTEE VALIDITY

### SELF-LEARNING AND FUNCTIONS

The selection of the protocol comes through **SELF-RECOGNITION**; after the connections are terminated by inserting the module to the connector, the unit will carry out in about one second, the synchronization indicated with **quick RED flashes** of the module's LED.

As soon as the synchronization is carried out, the vehicle's protocol is selected; this operation is confirmed by the lighting up of the **GREEN FIXED LIGHT** of the module's LED.

The unit is ready to work.



### TROUBLESHOOTING

- The unit doesn't work and the LED is switched off.
- Verify the power supply connections.
- The correctly powered unit doesn't work and the LED is switched off.
- Verify the CANBUS connections.
- The unit is correctly connected and the RED LED flashes quickly.
- The unit can't be synchronized with the CANBUS; contact Paser.
- The unit is correctly connected and the RED LED flashes in an irregular way.
- Verify the CANBUS connections.
- The unit is correctly connected and the RED LED is on.
- The unit has carried out the synchronization with the CANBUS but can't recognize the vehicle; contact Paser.

**MODE 3  
2 PHONE BUTTONS**

- Answer an incoming call**  
Press ANSWER button quickly
- Refuse an incoming call**  
Press CLOSE button quickly
- End a call**  
Press CLOSE button quickly
- Start a vocal call**  
Press ANSWER button quickly
- Redial the last number**  
Press ANSWER button for a long time
- Enter discrete mode**  
Press ANSWER button quickly
- Exit from discrete mode**  
Press ANSWER button quickly
- Increase the volume**  
Press the VOL+ quickly
- Lower the volume**  
Press the VOL — quickly

**To enter the menu**

Press twice the sequence SEEK+ quickly, followed by SEEK- quickly  
(SEEK+ / SEEK — / SEEK+ / SEEK —)

**Go forward to the menu**

Press SEEK+ within 10 seconds or  
Press the VOL+

**Go backwards to the menu**

Press SEEK— within 10 seconds or  
Press the VOL—

**To confirm a menu selection**

Press ANSWER button quickly






**To delete a menu selection**

Press CLOSE button quickly

**To reset the kit**

Press the sequence VOL—quickly, followed by VOL+ quickly five times  
(VOL- / VOL + / VOL- / VOL +)

**CANBUS CONNECTIONS  
(WIRES OUTPUT VIEW)**




**CANBUS CONNECTIONS  
(WIRES OUTPUT VIEW)**




**FAKRA**  
 C2 - C3 - C4  
 207 - 307 - 407- 508


CAN H  
 GREEN  
 CAN L  
 WHITE



BUTTONS	VOL +	VOL -	◀	▶	▲	▼	VOL + & -	MODE
FUNCTIONS	1	2	4	3	6	5	8	7

**CHRYSLER**

CH WHITE/ORANGE (POS 5)  
 CL WHITE (POS 6)




LEFT LEVER BEHIND ST. WHEEL  
 4  
7  
3

RIGHT LEVER BEHIND ST. WHEEL  
 1  
8  
2

**J. GRAND CHEROKEE  
COMPASS  
300 C**

**Jeep** **Dodge**

NITRO  
COMPASS 2012  
 CL WHITE/ORANGE (POS 2)  
 CH WHITE/GREY (POS 13)




LEFT LEVER BEHIND ST. WHEEL  
 4  
7  
3

RIGHT LEVER BEHIND ST. WHEEL  
 1  
8  
2

**NITRO  
COMPASS 2012**

**FIAT** **LANCIA**


GRANDE PUNTO  
IDEA - CROMA - STILO - BRAVO  
500  
 YPSILON



BUTTONS	+	-	▲	▼	🔊	SCR
FUNCTIONS	1	2	3	4	8	7

**FIAT**

CONNECTORS ARE BACK THE RADIO  
**FREEMONT**



**MODE 2  
ONE PHONE BUTTON**

Answer an incoming call

Press TEL button quickly

Refuse an incoming call

Press TEL button for a long time

End a call

Press TEL button for a long time

Start a vocal call

Press TEL button quickly

Redial the last number

Press TEL button for a long time

Enter discrete mode

Press TEL button quickly

Exit from discrete mode

Press TEL button quickly

Increase the volume

Press the VOL+ quickly

Lower the volume

Press the VOL — quickly

To enter the menu

Press twice the sequence SEEK+ quickly, followed by SEEK- quickly  
(SEEK+ / SEEK — / SEEK+ / SEEK — )

Go forward to the menu

Press SEEK+ within 10 seconds or  
Press the VOL+

Go backwards to the menu

Press SEEK— within 10 seconds or  
Press the VOL—

To confirm a menu selection

Press TEL button quickly

To delete a menu selection

Press TEL button for a long time

To reset the kit

Press the sequence VOL—quickly, followed by VOL+ quickly five times  
(VOL- / VOL + / VOL- / VOL + /VOL- / VOL + /VOL- / VOL + /VOL- / VOL +)

**MODE 1  
AUDIO BUTTONS (NO PHONE BUTTONS AVAILABLE)**

**Answer an incoming call**

Press VOL+ quickly

**Refuse an incoming call**

Press VOL — quickly

**End a call**

Press VOL — quickly

**Start a vocal call**

Press VOL+ quickly, followed by VOL– quickly

**Redial the last number**

Press VOL+ quickly, followed by VOL– for a long time

**Enter discrete mode**

Press VOL+ quickly

**Exit discrete mode**

Press VOL+ quickly, followed by VOL– quickly

**Increase the volume**

Press the sequence VOL+ quickly, followed by VOL– quickly many times till the required volume is reached

**Lower the volume (1 step)**

Press the sequence VOL — quickly, followed by VOL + quickly many times till the required volume is reached

**To enter the menu**

Press twice the sequence SEEK+ quickly, followed by SEEK– quickly (SEEK+ / SEEK — / SEEK+ / SEEK —)

**Go forward to the menu**

Press SEEK+ within 10 seconds or

Press the sequence VOL+ quickly, followed by VOL– quickly

**Go backwards to the menu**

Press SEEK– within 10 seconds or

Press the sequence VOL– quickly, followed by VOL+ quickly

**To confirm a menu selection**

Press VOL+ quickly







**To delete a menu selection**

Press VOL — quickly

**To reset the kit**

Press the sequence VOL– quickly, followed by VOL+ quickly five times (VOL- / VOL + / VOL- / VOL + /VOL- / VOL + /VOL- / VOL + /VOL- / VOL +)

**CANBUS CONNECTIONS  
(WIRES OUTPUT VIEW)**




## CANBUS CONNECTIONS (WIRES OUTPUT VIEW)



CORSA - ASTRA H - MERIVA  
NEW VECTRA  
SIGNUM - TIGRA - NEW ZAFIRA  
ANTARA

BUTTONS	VOL +	VOL -	▲	▼	⏪	⏩
FUNCTIONS	1	2	4	3	7	8

CAN H GREEN  
CAN L WHITE




CANBUS CONNECTIONS  
ON FAKRA OPEL



CAYENNE TURBO

CAN H GREEN  
CAN L WHITE

BUTTONS	+	-	◀	▶	🎵	MUTE
FUNCTIONS	1	2	4	3	7	8



ISO PORSCHE




MODUS - CLIO - MEGANE  
LAGUNA - ESPACE

RENAULT

BUTTONS	+	-	↺	↻	🔇	SCR
FUNCTIONS	1	2	4	3	8	7


CAN L WHITE  
CAN H GREEN

CAN L WHITE  
CAN H GREEN



CANBUS CONNECTIONS  
ON FAKRA RENAULT


KOLEOS



ALTEA - CORDOBA - LEON

BUTTONS	+	-	◀	▶	🔄	🔇
FUNCTIONS	1	2	4	3	7	8

CAN H GREEN  
CAN L WHITE



CANBUS CONNECTIONS  
ON FAKRA SEAT


## CANBUS CONNECTIONS (WIRES OUTPUT VIEW)



OCTAVIA II - YETI - SUPERB

BUTTONS	+	-	◀	▶	🔄	🔇
FUNCTIONS	1	2	4	3	7	8

CAN H GREEN  
CAN L WHITE



CANBUS CONNECTIONS  
ON FAKRA SKODA



FORTWO

GREEN	CH WHITE / GREEN (POS 6)
WHITE	CL GREEN (POS 9)


WIRES ARE UNDER THE DASHBOARD NEAR THE STEERING WHEEL



POLO 2009 - GOLF V - GOLFPLUS -  
TOURAN  
PASSAT - TOUAREG  
NEW TOUAREG - EOS  
MULTIVAN - TIGUAN

BUTTONS	+	-	◀	▶	🔄	🔇
FUNCTIONS	1	2	4	3	7	8

CAN H GREEN  
CAN L WHITE



CANBUS CONNECTIONS  
ON FAKRA VW



GOLF VII  
LEON 2013  
OCTAVIA 2013




SEAT

SKODA



CONNECTORS ARE BACK THE RADIO

CAN H GREEN  
CAN L WHITE



CANBUS CONNECTIONS  
ON FAKRA



V70

BUTTONS	+	-	◀	▶
FUNCTIONS	1	2	4	3

CAN H GREEN  
CAN L WHITE

