
		UNICAN PLUS			TABELLE RADIO RADIO TABLES		07.1217 REV 2.17 da/from FWP007UNUN209_85_1C		
FUNC.	CLARION	KENWOOD	JVC	ALPINE	PIONEER	PIONEER	SONY PHONOCAR VM040/VM041 Alpine IVE-W560BT IVE-W560BT-R		NON USATO NOT USED
	FILO E IR	FILO E IR	FILO E IR	FILO E IR	IR	FILO	FILO		
FLASH	1	2	3	4	5	6	7		8
1	VOLUME +								
2	VOLUME —								
3	MEM +	SEEK +							
4	MEM -	SEEK —							
5	BAND	FM	BAND +	MEM +	MEM +	MEM +	MEM +		
6	Input_sel	AM	BAND —	MEM -	MEM -	MEM -	MEM -		
7	SRC	SRC	SRC	SRC	SRC	SRC	SRC		
8	MUTE	MUTE	MUTE	MUTE	MUTE	MUTE	MUTE		
9	X	PHONE ANSWER	PHONE ANSWER	PHONE ANSWER	X	PHONE ANSWER	PHONE ANSWER		
10	X	PHONE CLOSE	PHONE CLOSE	PHONE CLOSE	X	PHONE CLOSE	PHONE CLOSE		
11	X	VOICE RECALL	X	X	X	X	X		

FUNC.	QUANTUM	NON USATO NOT USED	PANASONIC 1	NON USATO NOT USED	PHONOCAR VM040 IR ZENEC ZE-MC194	NON USATO NOT USED	BLAUPUNKT	SONY	NON USATO NOT USED	ECLIPSE AVN2227P AVN4429 AVN726EE SOLO SU RICHIESTA/ ONLY ON REQUEST
	FILO E IR		FILO E IR		FILO E IR		FILO E IR	IR		FILO
FLASH	9	10	11	12 / 13	14	15	16	17	18 / 19 / 20 21 / 22	23
1	X	VOLUME +								
2	X	VOLUME —								
3	P +	SEEK +								
4	P —	SEEK —								
5	X		X		UP		MEM+	MEM +		X
6	X		X		DOWN		BAND	MEM -		X
7	X		SRC		SRC		SRC	SRC		SRC
8	X		MUTE		MUTE		MUTE	MUTE		X
9	X		X		X		X	X		X
10	X		X		X		X	X		X

FUNC.	NON USATO NOT USED	ECLIPSE AVN8826 CD8445E CD4525E AVN726EE	PHONOCAR 1 FORYOU CMU128-CM123 VM020-VM021 VM024	PHONOCAR 2 DM736 VM016 MACROM M-DVD4650R	PHONOCAR 3 (1)VM029-VM030 VM031 -VM032 VM036	NON USATO NOT USED	MACROM	NON USATO NOT USED	PHONOCAR 11 VM057
		IR	FILO E IR	FILO E IR	IR		IR		FILO
FLASH	24 / 25	26	27	28	29	30/ 31 / 32	33	34	35
1	VOLUME +								
2	VOLUME —								
3	SEEK +								
4	SEEK —								
5		MEM +	PLAY	PLAY	PLAY		UP		UP
6		MEM -	BAND	BAND	BAND		DOWN		DOWN
7		SRC	SRC	SRC	SRC		MODE		SOURCE
8		MUTE	MUTE	MUTE	MUTE		MUTE		MUTE
9		X	X	X	PHONE ANSWER		X		PHONE ANSWER
10		X	X	X	PHONE CLOSE		X		PHONE CLOSE

		UNICAN PLUS			TABELLE RADIO RADIO TABLES			07.1217 REV 2.17 da/from FWP007UNUN209_85_1C	
FUNC.	NON USATO NOT USED	ZENEC 1 ZE-MC192 ZE-NC2040 XZENT XT8020	ZENEC 2 ZE-MC192 (SMART-DIAL- REMOTE CON- TROL)	HARDSTONE 1 HS DPM62 HS DPM63	HARDSTONE 2 HS DPM30	HARDSTONE 3 HS DPM31 HS DPM61 FILO E IR PHONOCAR VM017 VM018 FILO E IR VM035	HARDSTONE 4 HS DPM36 HS DPM70	HARDSTONE 5 HS CD1970	
		FILO E IR	FILO E IR	FILO E IR	IR	IR	IR	IR	
FLASH	36/37/38/39/40	41	42	43	44	45	46	47	
1	VOLUME +								
2	VOLUME —								
3	SEEK +		UP	SEEK +					
4	SEEK —		DOWN	SEEK —					
5		OK	UP	>>	BAND	BAND	BAND	BAND	
6		DOWN	DOWN	<<	EQ	EQ	EQ	EQ	
7		SOURCE	OK/MENU	SOURCE	SOURCE	SOURCE	SOURCE	SOURCE	
8		MUTE	STORE	MUTE	MUTE	MUTE	MUTE	MUTE	
9		PHONE (OK)	X	X	X	PHONE ANSWER	X	X	
10		X	X	X	X	PHONE CLOSE	X	X	


FUNC.	NON USATO NOT USED	KENWOOD DT	CLARION BS RCB-165	ALPINE 2 RUE-4912 DVD	ALPINE 3 RUE4912 NAVI	NON USATO NOT USED	ECLIPSE 3 RMC101	HARDSTONE 6 HS DPM7G	NON USATO NOT USED
FLASH		FILO E IR	IR	IR	IR		IR	IR	
	48 / 49	50	51	52	53	54	55	56	57
1		X	VOLUME +	VOLUME +					
2		X	VOLUME —	VOLUME —					
3		UP	MEM +	SEEK +					
4		DOWN	MEM —	SEEK —					
5		X	INPUT SEL	UP	UP		MEM+	UP	
6		X	BAND	DOWN	DOWN		MEM-	DOWN	
7		X	SRC	SRC	SRC		SRC	SRC	
8		X	MUTE	MUTE	X		X	MUTE	
9		X	X	X	X		X	PHONE ANSWER	
10		X	X	X	X		X	PHONE CLOSE	

FUNC.	HARDSTONE7 HS DPM8G PHONOCAR N6205	MACROM2 M-DVD5551R M-DVD6545R	NON USATO NOT USED	BECKER TRAFFIC PRO Solo su richiesta	MACROM3 M-DVD6555R M-DVD6556R PHONOCAR VM041 IR	MACROM4 M-DVD5542R M-DVD5561R M-DVD5562R M-DVD5541R	NON USATO NOT USED	ZENEC 3 ZE-NC520 ZE-NC524
	FILO E IR	IR	60/61/62 63/64/65 66	FILO	FILO E IR	FILO E IR		FILO E IR
FLASH	58	59		67	68	69	70/71/72	73
1	VOLUME +							
2	VOLUME —							
3	SEEK +							
4	SEEK —							
5	UP	PLAY/PAUSA		MODE	UP	PLAY/PAUSE		BAND/STOP
6	DOWN	STOP/BAND		X	DOWN	BAND		DOWN
7	SOURCE	MODE		X	SRC	SRC		SRC
8	MUTE	MUTE		X	MUTE	MUTE		MUTE
9	X	X		X	PHONE ANSWER	PHONE ANSWER		PHONE ANSWER
10	X	X		X	PHONE CLOSE	PHONE CLOSE		PHONE CLOSE

		UNICAN PLUS				TABELLE RADIO RADIO TABLES		07.1217 REV 2.17 da/from FWP007UNUN209_85_1C	
FUNC.	NON USATO NOT USED	JVC2	ALPINE4	PIONEER2	PIONEER2	PHONOCAR 4 VM05	NON USATO NOT USED	BLAUPUNKT 2 ATLANTA110 MADRID210 TORONTO410BT SAN FRANCISCO310	BLAUPUNKT NEW YORK 800
		FILO E IR	FILO E IR	IR	FILO	FILO E IR		FILO E IR	FILO E IR
FLASH	74	75	76	77	78	79	80/81/82	83	84
1	VOLUME +								
2	VOLUME —								
3		UP				> (RIC.RADIO)		SEEK +	
4		DOWN				>> (TRACK +)		SEEK —	
5		SEEK +	SEEK +	SEEK +	SEEK +	PLAY		UP	OK
6		SEEK —	SEEK —	SEEK —	SEEK —	BAND		DOWN	DOWN
7		SRC	SRC	SRC	SRC	SRC		SOURCE	SOURCE
8		MUTE	MUTE	MUTE	MUTE	MUTE		MUTE	MUTE
9		PHONE ANSWER	PHONE ANSWER	X	PHONE ANSWER	PHONE ANSWER		PHONE ANSWER	PHONE ANSWER
10		PHONE CLOSE	PHONE CLOSE	X	PHONE CLOSE	PHONE CLOSE		PHONE CLOSE	PHONE CLOSE

FUNC.	PHONOCAR 5 VM066	TV DAS	NON USATO NOT USED	BLAUPUNKT NEW YORK 800 resistiva	NON USATO NOT USED	PHONOCAR 6 VM037	SONY HW OLD	PIONEER HW OLD	HARDSTONE8 HS-DPM71 HS-DPM64 HS-DPM69	PHONOCAR 7 VM033
	FILO E IR	IR		FILO		FILO E IR	FILO	FILO	FILO E IR	FILO E IR
FLASH	85	86	87/88/89	90	91	92	93	94	95	96
1	VOLUME +									
2	VOLUME —									
3	SEEK +									
4	SEEK —									
5	PLAY/PAUSE	X		X		UP	MEM +	MEM +	>>	UP
6	X	X		X		DOWN	MEM -	MEM -	<<	DOWN
7	SRC	X		SRC or PHONE ANSWER		MODE	SRC	SRC	SOURCE	SRC
8	MUTE	X		MUTE or PHONE CLOSE		MUTE	MUTE	MUTE	MUTE	MUTE
9	PHONE ANSWER	X		PHONE ANSWER or SRC		X	X	X	PHONE ANSWER/ BACK	X
10	PHONE CLOSE	X		PHONE CLOSE or MUTE		X	X	X	PHONE CLOSE/ ROOT	X

FUNC.	MACROM 5 M-DVD7702 M-DVD7701 M-DVD7602 M-DVD7601		CLARION 2 NX-501E NX-502E NX-503E NX-404E NX-504E		WR9210 RADIO 500	BLACKSTONE BS-ARM11	RADIO JEEP PHONOCAR	RADIO AUDI A4 PHONOCAR
	IR		FILO E IR		FILO	FILO E IR	FILO E IR	FILO E IR
FLASH	97		98		99	100	101	102
1	VOLUME +							
2	VOLUME —							
3	SEEK +		MEM + / SCAN +		SEEK +			
4	SEEK —		MEM — / SCAN —		SEEK —			
5	RIGHT		SCAN +		SOURCE	X	X	X
6	LEFT		SCAN —		MUTE	X	X	X
7	SRC		MUTE		X	SOURCE	SOURCE	SOURCE
8	MUTE / PWR		TA		X	MUTE	MUTE	MUTE
9	AMS/PHONE ANSWER		PHONE ANSWER		X	PHONE ANSWER	PHONE ANSWER	X
10	BAND/PHONE CLOSE		PHONE CLOSE/BAND		X	PHONE CLOSE	PHONE CLOSE	X

			UNICAN PLUS			TABELLE RADIO RADIO TABLES			07.1217 REV 2.17 da/from FWP007UNUN209_85_1C		
FUNC.	PIONEER FILARE OLD2	NON USATO NOT USED	ECLIPSE 4 AVN827GA	PHONOCAR 8 VM08	CONSOLI 1	JVC3	PHNOCAR 9 RENAULT CAPTURE	PHONOCAR 10 VM025 - VM026	NON USATO NOT USED	AUDIOLINK CASKA FOR YOU	*BLAUPUNKT Brisbane 230 Stockholm 370 HARDWARE DEDICATED
	FILO E IR		FILO	FILO E IR	FILO E IR	FILO	FILO E IR	FILO E IR	111 112 113	FILO	FILO RES
FLASH	103	104	105	106	107	108	109	110		114	115
1	VOLUME +										
2	VOLUME —										
3	MEM +		SEEK +								
4	MEM -		SEEK —								
5	SEEK +		SOURCE	SOURCE	UP	BAND +	SOURCE	SOURCE		X	SOURCE
6	SEEK -		MUTE	MUTE	DOWN	BAND —	MUTE	MUTE		X	MUTE
7	SRC		PHONE ANSWER	X	SOURCE	SRC	X	X		SRC	PHONE ANSWER
8	MUTE		VOICE	X	MUTE	MUTE	X	X		MUTE	PHONE CLOSE
9	X		PHONE ANSWER / CLOSE	PHONE ANSWER	PHONE ANSWER	PHONE ANSWER	PHONE ANSWER	X		PHONE ANSWER	X
10	X		PHONE CLOSE	PHONE CLOSE	PHONE CLOSE	PHONE CLOSE	PHONE CLOSE	X		PHONE CLOSE	X

ATTENZIONE

IL PROFILO RADIO 23 (ECLIPSE AVN2227P) SI PUO' AVERE PERDENDO I PROFILI RADIO 6 (PIONEER) E 7 (SONY).

IL PROFILO 90 PERMETTE DI VEDERE FINO AD 8 TASTI MA GESTISCE SOLO 6 FUNZIONI SULLA RADIO.

⁽¹⁾ LA RADIO PHONOCAR VM029 HA SOLO LE SEGUENTI FUNZIONI: VOLUME-, VOLUME+, SEEK-, SEEK+, MODE E MUTE.

PER IL PROFILO RADIO 105 (ECLIPSE AVN827GA) LE FUNZIONI 7 E 10 SERVONO PER L'APPRENDIMENTO DEI TASTI TELEFONO

IL PROFILO RADIO 108 (JVC3) ATTIVA L'OPZIONE n°22

CAUTION

YOU CAN HAVE RADIO PROFILE 23 BUT IT'S LOST RADIO PROFILE 6 (PIONEER) AND PROFILE RADIO 7 (SONY).


IT'S POSSIBLE TO SEE 8 BUTTONS/LEVERS WITH PROFILE 90, BUT YOU CAN TO MANAGE ONLY 6 FUNCTIONS OF THE RADIO.

⁽¹⁾ PHONOCAR RADIO VM029 HAS ONLY THE FOLLOWING FUNCTIONS: VOLUME-, VOLUME+, SEEK-, SEEK+, MODE AND MUTE.

PROFILE RADIO 105 (ECLIPSE AVN827GA) FUNCTIONS 7 AND 10 ARE LEARNING KEY TELEPHONE

PROFILE RADIO 108 (JVC 3) ENABLE THE OPTION N° 22

MODELLO RADIO / RADIO MODEL	ADATTATORE RADIO/ RADIO ADAPTER
CLARION, JVC; MACROM M-DVD5542R, M-DVD5561R, M-DVD5562R; BLAUPUNKT NEW YORK 800; PHONOCAR VM033, VM037, VM029, VM057; CONSOLI 1;	CBL007UNJV12
PIONEER; SONY; PHONOCAR VM040 (flashes 7), VM041 (flashes 7), **VM024, VM025, VM026; *GRUNDIG DELPHI X350BT, DELPHI X440BT; BLAUPUNKT NEW YORK 800 RESISTIVA; WR9210 RADIO 500.	CBL007UNPI12
ALPINE.	CBL007UNAL22
KENWOOD.	CBL007UNKE11
PANASONIC; PHONOCAR FORYOU, CMU128, CM123, VM020, VM021, DM736, VM016, VM017, VM030, VM031, VM032, VM036, VM050, N6205, VM066, VM081; HARDSTONE HS DPM61, HS DPM62, HS DPM63, HS DPM31, HS DPM7G, HS DPM8G, HS DPM71, HS DPM69, HS DPM64; MACROM M-DVD6555R, M-DVD6556R; RADIO JEEP; RADIO AUDI A4.	CBL007UNPN21
BLAUPUNKT; BLAUPUNKT 2 ATLANTA110, MADRID210, TORONTO410BT, SAN FRANCISCO 310.	CBL007UNBL12
*VDO.	CBL007UNVD11
ECLIPSE AVN2227P, AVN4429, AVN726EE. BLAUPUNKT Brisbane 230 Stockholm 370 (USARE SOLO FILO VIOLA ESU KEY1/USE VIOLET ONLY TO KEY1)	CBL007UNEL11
BLACHSTONEBS-ARM11 Radio ad apprendimento resistivo, si deve impostare sulla radio 10kΩ, il cambio sorgente è sul filo blu della radio (MODE-KEY) da collegare con il nostro marrone, il filo rosa della radio (AD-KEY) va collegato con il nostro viola ed il filo nero della radio con il nostro nero. / Radio resistive to learning, to be set on 10k radio, the transmission source is on the blue wire to the radio (MODE-KEY) to be connected with our brown, the pink wire to the radio (AD-KEY) should be connected with our purple and the black wire to the radio with our black.	
* DISPONIBILE SOLO CON HARDWARE DEDICATO / AVAILABLE ONLY WITH DEDICATED HARDWARE	
** TAGLIARE FILO IN POSIZIONE 2 DEL MICROFIT / TO CUT WIRE IN POSITION 2 OF MICROFIT.	



Le informazioni riportate in questo manuale e nei suoi allegati sono puramente a scopo informativo pertanto possono subire modifiche senza preavviso. Al momento della pubblicazione le informazioni risultano corrette ed attendibili. Tuttavia Paser non può essere ritenuta responsabile per eventuali conseguenze derivanti da errori, omissioni o incongruenze del presente manuale e dei suoi allegati (ad. es. per l'eventuale mancato recupero di configurazioni audio originali dei veicoli). Paser si riserva il diritto di migliorare/modificare il prodotto o il manuale senza l'obbligo di notifica agli utenti.
Information in this guide and its attachments are for information purposes only, therefore, they are subject to change without notice. At the time of publication the information is correct and reliable. However Paser can not be held responsible for any consequences resulting from errors, omissions or incongruence of this manual (for ex. missed audio configuration back-up of the vehicles). Paser reserves the right to improve / change the product or manual without obligation to notify users.