





		MAHINDRA KUV100 	2020> PROTOCOLLO RESISTIVO 2020> RESISTIVE PROTOCOL
---	---	--	--



POSIZIONE CONNETTORE: VANO AUTORADIO - CONNECTOR LOCATION: CAR RADIO SLOT


DIETRO L'AUTORADIO SI TROVANO I CONNETTORI RADIO OEM.
BEHIND THE CAR RADIO THERE ARE RADIO OEM CONNECTORS.



Vista connettore uscita cavi
Connector view: wires output

COMANDI AL VOLANTE - STEERING WHEEL COMMANDS

CAN H FILO GIALLO POS 3
CAN L FILO VERDE POS 14
CAN H YELLOW WIRE POS 3
CAN L GREEN WIRE POS 14



FUNZIONI - FUNCTIONS

1	VOL+
2	VOL —
3	SEEK + or ANSWER CALL
4	SEEK — or CLOSE CALL
5	MODE
6	MUTE

PRODOTTI SUGGERITI - SUGGESTED PRODUCTS

LOGICAN - UNICOM - UNICO DUAL - UNIKA - MAESTRO

Le informazioni riportate in questo manuale sono puramente a scopo informativo pertanto possono subire modifiche senza preavviso. Al momento della pubblicazione le informazioni risultano corrette ed attendibili. Tuttavia Paser non può essere ritenuta responsabile per eventuali conseguenze derivanti da errori od omissioni del presente manuale. Paser si riserva il diritto di migliorare/modificare il prodotto o il manuale senza l'obbligo di notifica agli utenti. Information in this guide are purely for information purposes, therefore, are subject to change without notice. At the time of publication the information is correct and reliable. However Paser can not be held responsible for any consequences resulting from errors or omissions in this manual. Paser reserves the right to improve / change the product or manual without obligation to notify users.