



## MediaDAB-HD Upgrading Procedure

For this kind of device are available 2 different upgrading systems:

### **Application Upgrade (FWP059UNDBXX.fwp)**

This upgrade rectifies/improves the working of interface basic functions as for example menu management, track reproduction and DAB functions.

### **Speech Synthesis Upgrade (MediaDAB-HD\_XXX\_XXX\_XXX\_XXX\_XXX.vox)**

The device, in the standard configuration, is provided with four languages. However it is possible to substitute them with other languages or with the most updated version.

## **Application Upgrade**

Download updating file: **MediaDAB-HD\_Application\_vX.X.zip** from the website **www.paser.it**.

Extract the file: **FWP059UNDBXX.fwp** from the archive.

Copy file **FWP059UNDBXX.fwp** into the **ROOT** of a USB pen which has been formatted with a **FAT32\*** file system.

Connect USB pen to the device.

Switch on the device.

Enter the updating menu following the path:

**Menu ->> Setup ->> System ->> Upgrade System Version**

Follow vocal instructions.

## **Upgrade Voices**

Download updating file: **MediaDAB-HD\_Voice\_XXX-XXX-XXX-XXX\_vX.X.zip** from the website **www.paser.it**.

Extract the file: **MediaDAB-HD\_XXX\_XXX\_XXX\_XXX\_XXX.vox** from the archive.

Copy file **MediaDAB-HD\_XXX\_XXX\_XXX\_XXX\_XXX.vox** into the **ROOT** of a USB pen which has been formatted with a **FAT32\*** file system.

Connect USB pen to the device.

Switch on the device.

Enter the updating menu following the path:

**Menu ->> Setup ->> Voice ->> Upgrade Voice**

Follow vocal instructions.

RDS system will indicate the bytes count-down to the upgrade end.

\*To execute the upgrade it is necessary a USB pen compatible.