
		UNICO DUAL PLUS			TABELLE RADIO RADIO TABLES			UNICO DUAL	
FUNC.	CLARION	KENWOOD	JVC	PIONEER		SONY PHONOCAR VM040/VM041 Alpine IVE-W560BT IVE-W560BT-R Solo su richiesta versione filo.		ALPINE	NOT USED 7 8 9 10 11 12
	FILO E IR	FILO E IR	FILO E IR	FILO	IR	FILO	IR	FILO E IR	
FLASH	1	2	3	4		5		6	
1	VOLUME —								
2	VOLUME +								
3	SEEK —								
4	SEEK +								
5	FUNC	SOURCE	SOURCE	MODE	MODE	SOURCE	SOURCE	SOURCE	
6	MUTE	MUTE	MUTE	MUTE	MUTE	MUTE	MUTE	MUTE	
7	BAND	UP	UP	UP	BAND	UP	OFF	UP	
8	DISP	VOICE	DOWN	DOWN	UP	DOWN	UP	DOWN	
9	TA	PHONE ANSWER	PHONE ANSWER	X	DOWN	X	DOWN	PHONE ANSWER	
10	INPUT SEL	PHONE CLOSE	PHONE CLOSE	X	FUNC	X	BAND	PHONE CLOSE	

FUNC.	NOT USED	PHONOCAR VM040 ZENEC ZE-MC194	NOT USED 17 18 19 20 21 22 23 24 25	PHONOCAR 1 FORYOU CMU128 CM123 VM020 VM021 VM024	PHONOCAR 2 DM736 VM016 MACROM M-DVD4650R IR	PHONOCAR 3 (1)VM029 VM030 VM031 VM032 VM036	NOT USED 29 30 31 32 33 34 35 36 37 38 39 40 41	HARDSTONE 3 HS DPM31 HS DPM61 PHONOCAR VM017 VM018 VM035 IR	NOT USED 43 44 45 46 47 48 49 50 51 52 53
		FILO E IR		FILO E IR	FILO E IR	FILO E IR		IR	
FLASH	13 14 15	16		26	27	28		42	
1	VOLUME —								
2	VOLUME +								
3	SEEK —								
4	SEEK +								
5		SOURCE		MODE	MODE	MODE		SRC	
6		MUTE		MUTE	MUTE	MUTE		MUTE	
7		UP		PLAY/PAUSE	PLAY/PAUSE	PLAY/PAUSE		BAND	
8		DOWN		BAND	BAND	BAND		UP	
9		BAND		INT	REPEAT	PHONE ANSWER		PHONE ANSWER	
10		PWR		REPEAT	POWER	PHONE CLOSE		PHONE CLOSE	

FUNC.	HARDSTONE7 HS DPM8G PHONOCAR N6205	NOT USED 55 56 57 58 59 60 61	MACROM3 M-DVD6555R M-DVD6556R PHONOCAR VM041 IR	NOT USED 63 64 65 66 67 68 69	PHONOCAR 4 VM050	NOT USED 71 72 73 74	PHONOCAR 5 VM066	NOT USED 76 77 78 79	PHONOCAR 6 VM037	NOT USED 81 82	PHONOCAR 7 VM033
	FILO E IR				FILO E IR		FILO E IR		FILO E IR		FILO E IR
FLASH	54	61	62		70		75		80		83
1	VOLUME —										
2	VOLUME +										
3					>> (NEXT TRACK)	SEEK —					
4					> (Radio Tuner)	SEEK +					
5	MODE		SRC		SRC		SRC		SRC		SRC
6	MUTE		MUTE		MUTE		MUTE		MUTE		MUTE
7	BAND		UP		PLAY/PAUSE		PLAY		BAND		BAND
8	RPT		DOWN		BAND		POWER		UP		UP
9	PLAY/PAUSE		PHONE AN- SWER		PHONE ANSWER		PHONE ANSWER		DOWN		DOWN
10	POWER		PHONE CLOSE		PHONE CLOSE		PHONE CLOSE		PLAY		ENTER


	UNICO DUAL PLUS	TABELLE RADIO RADIO TABLES	UNICO DUAL
---	-----------------	-------------------------------	------------

FUNC.	NOT USED 84	CLARION 2 NX-501E NX-502E NX-503E NX-404E NX-504E	NOT USED 86	RADIO JEEP PHONOCAR	RADIO AUDI A4 PHONOCAR	CLARION 3	PHONOCAR 8 VM081	PHONOCAR 9 RADIO CAPTUR	PHONOCAR 10 VM025 VM026
FLASH		FILO E IR		FILO E IR	FILO E IR	FILO IR	FILO E IR	FILO E IR	FILO E IR
		85		87	88	89	90	91	92
1	VOLUME —								
2	VOLUME +								
3	SEEK —								
4	SEEK +								
5		SOURCE/PWR		SOURCE	SOURCE	SOURCE	SOURCE		
6		MUTE		MUTE	MUTE	MUTE	MUTE		
7		RDM		X	X	X	X	PLAY/PAUSE	X
8		TA		X	X	X	X	RPT	X
9		PHONE ANSWER		PHONE ANSWER	X	PHONE ANSWER	PHONE ANSWER	PHONE ANSWER	X
10		PHONE CLOSE/BAND		PHONE CLOSE	X	PHONE CLOSE	PHONE CLOSE	PHONE CLOSE	X

FUNC.	RADIO AD APPENDIMENTO RESISTIVO 8 TASTI <i>RADIO WITH RESISTIVE LEARNING SYSTEM 8 BUTTONS</i>	NOT USED	PHONOCAR 11 VM057	KENWOOD NRM	MACROM USCITA RESISTIVA PER TASTI TELEFONO DUCATO VEDERE CONNESSIONE
	FILO		FILO	FILO	FILO
FLASH	93	94	95	96	97
1	VOLUME —				QUESTO PROFILO PERMETTE DI RECUPERARE I TASTI TELEFONO CON LE RADIO MACROM AD APPENDIMENTO RESISTIVO.
2	VOLUME +				
3	SEEK —				
4	SEEK +				
5	SRC	X	SOURCE	SOURCE	THIS PROFILE ALLOWS TO RECOVER THE PHONE KEYS WITH THE MACROM RADIO WITH RESI- STIVE LEARNING.
6	MUTE	X	MUTE	MUTE	
7	X	X	UP	UP	
8	X	X	DOWN	VOICE	
9	PHONE ANSWER	X	PHONE ANSWER	PHONE ANSWER	
10	PHONE CLOSE	X	PHONE CLOSE	PHONE CLOSE	

SCHEMA CONNESSIONI UNICO DUAL MACROM SU DUCATO 2021



	UNICO DUAL PLUS	TABELLE RADIO RADIO TABLES	UNICO DUAL
AVN2227P: marrone tacche grigie (radio) va con il Viola (interfaccia)/ marrone tacche grigie - Nero (radio) va con il Marrone (interfaccia).			
AVN4429 e AVN726EE: marrone tacche grigie (radio) va con il Marrone (interfaccia)/ marrone tacche grigie - Nero (radio) va con il Viola (interfaccia).			

AVN2227P: brown - gray (radio) with violet (interface)/ brown—gray - black (radio) with brown (interface).
AVN4429 e AVN726EE: brown - gray (radio) with brown (interface)/ brown - gray - black (radio) with violet (interface).


ATTENZIONE

I PROFILI 4 (PIONEER), 5 (SONY), 7 (VDO) E 20 (ECLIPSE) SI ESCLUDONO A VICENDA.

⁽¹⁾ LA RADIO PHONOCAR VM029 HA SOLO LE SEGUENTI FUNZIONI: VOLUME-, VOLUME+, SEEK-, SEEK+, MODE E MUTE.**CAUTION**

PROFILES 4 (PIONEER), 5 (SONY), 7 (VDO) AND 20 (ECLIPSE) ARE MUTUALLY EXCLUSIVE.

⁽¹⁾ PHONOCAR RADIO VM029 HAS ONLY THE FOLLOWING FUNCTIONS: VOLUME-, VOLUME+, SEEK-, SEEK+, MODE AND MUTE.

MODELLO RADIO / RADIO MODEL	ADATTATORE RADIO/ RADIO ADAPTER
CLARION, JVC; PHONOCAR VM033, VM037, VM029, VM057;	CBL007UNJV12
PIONEER; SONY; PHONOCAR VM040 (flashes 7), VM041 (flashes 7), **VM024, VM025, VM026;	CBL007UNPI12
ALPINE. Le radio Alpine IVE-W560BT IVE-W560BT-R hanno hardware dedicato e necessitano del CBL007UNAL22.	CBL007UNAL22
KENWOOD.	CBL007UNKE11
PANASONIC; PHONOCAR FORYOU, CMU128, CM123, VM020, VM021, DM736, VM016, VM017, VM030, VM031, VM032, VM036, VM050, N6205, VM066, VM081; RADIO JEEP; RADIO AUDI A4.	CBL007UNPN21
RADIO AD APPRENDIMENTO RESISTIVO 8 TASTI / RADIO WITH RESISTIVE LEARNING SYSTEM 8 BUTTONS	CBL039UNFY11
<p>CONNESSIONE / CONNECTION</p> 	
* DISPONIBILE SOLO CON HARDWARE DEDICATO / AVAILABLE ONLY WITH DEDICATED HARDWARE	
** TAGLIARE FILO IN POSIZIONE 2 DEL MICROFIT / TO CUT WIRE IN POSITION 2 OF MICROFIT. 